




Walk-Behind Broadcast Spreaders


TS-50 & TS-70

Parts List



TS-50 WALK-BEHIND BROADCAST SPREADER

SPREADER KITS: MODEL TS-50



TS-50 WALK-BEHIND BROADCAST SPREADER


SPREADER KIT COMPONENTS: MODEL TS-50

TS-50 Spreader Components							
Item	Part	Qty	Description	Item	Part	Qty	Description
1		1	Handle Bar Assembly	4		1	Hopper Assembly
2		1	Broadcaster Assembly	5		1	Controls Assembly
3		1	Frame Assembly				
Item 1 79924 Handle Bar Assembly							
6		2	Upper Handle Square w/Grip	9	79859	2	Grip, 7.5" Long
7		1	Handle Shaft, Square	10		4	1/4-20 Locknut, Nylon Insert
8		2	Lower Handle, Square	11		2	1/4-20 x 2 Hex Cap Screw
Item 2 79925 Broadcaster Assembly							
12		1	Floating Gearbox	16	79864	2	Pneumatic Drive Wheel Stud
13		1	Axle, Coined	17		1	9" Round Impeller, Dished
14		2	3/16 x 2 Cotter Pin SS	18		2	Axle Bearing (large)
15		2	3/16 x 1 Cotter Pin SS	19		2	Axle Bushing (small)
Item 3 79926 Frame Assembly							
20		1	Frame	23		2	1/4-20 x 1-1/2 Hex Machine Screw
21		4	1/4-20 Locknut Nylon Insert SS	24		1	Frame Foot
22		2	1/4-20 x 2-1/4 Hex Cap Screw				
Item 4 79927 Hopper Assembly							
21		6	1/4-20 Locknut Nylon Insert SS	30		2	1/4-20 x 1 Hex Machine Screw SS
25		1	Square Screen	31		2	#8 x 3/8 Phillips Head Tapping Screw
26		1	Hopper Assembly	32		2	#6 x 3/8 Type 25 Phillips Head Pan Screw SS
27		1	Agitator	33		1	Shut-Off Plate
28		1	Hopper Bushing	34		1	Shut-Off Support, Large
29		4	1/4-20 x 1-1/2 Phillips Head Machine Screw SS				
Item 5 79928 Controls Assembly							
11		2	1/4-20 x 2 Hex Cap Screw	40		1	1/4-20 Hex Nut
35		1	Gauge & Lever Assembly	41		1	Pivot Rod
36		1	Pivot & Bracket Assembly	42		1	Cross Brace, 11.25"
37		1	Spacer (pivot link)	43		1	Frame Brace
38		1	Wing Nut Assembly	44		1	1/4-20 x 1 Carriage Bolt
39		1	Control Rod				
Accessories							
45*	WSC-030	1	Heavy-Duty Rain Cover	46*	PDK-030	1	3-Side Deflector Kit
SS = Stainless Steel							

* Accessory only.

TS-70 WALK-BEHIND BROADCAST SPREADER

TS-70 KIT COMPONENTS



TS-70 WALK-BEHIND BROADCAST SPREADER


SPREADER KIT COMPONENTS: MODEL TS-70

TS-70 Spreader Components							
Item	Part	Qty	Description	Item	Part	Qty	Description
1		1	Handle Bar Assembly	4		1	Hopper Assembly
2		1	Broadcaster Assembly	5		1	Controls Assembly
3		1	Frame Assembly				
Item 1 79931 Handle Bar Assembly							
6		2	Upper Handle Square w/Grip	9	79859	2	Grip, 7.5" Long
7		1	Handle Shaft, Square	10		10	1/4-20 Locknut, Nylon Insert
8		2	Lower Handle, Square	11		2	1/4-20 x 2 Hex Cap Screw
Item 2 79932 Broadcaster Assembly							
12		1	Floating Gearbox	16	79864	2	Pneumatic Drive Wheel Stud
13		1	Axle, Coined	17		1	9" Round Impeller, Dished
14		2	3/16 x 2 Cotter Pin SS	18		2	Axle Bearing (large)
15		2	3/16 x 1 Cotter Pin SS	19		2	Axle Bushing (small)
Item 3 79933 Frame Assembly							
20		1	Frame	23		2	1/4-20 x 1-1/2 Hex Cap Screw SS
21		10	1/4-20 Locknut Nylon Insert SS	24		1	Frame Foot
22		2	1/4-20 x 2-1/4 Hex Cap Screw				
Item 4 79934 Hopper Assembly							
21		6	1/4-20 Locknut Nylon Insert SS	30		2	1/4-20 x 1 Hex Cap Screw SS
25		1	Square Screen	31		2	#8 x 3/8 Phillips Head Tapping Screw
26		1	Hopper Assembly	32		2	#6 x 3/8 Type 25 Phillips Head Pan Screw SS
27		1	Agitator	33		1	Pro Shut-Off Plate
28		1	Hopper Bushing	34		1	Shut-Off Support, Small
29		4	1/4-20 x 2 Phillips Head Machine Screw SS	35		1	Shut-Off Support, Large
Item 5 79935 Controls Assembly							
11		2	1/4-20 x 2 Hex Cap Screw	41		1	1/4-20 Hex Nut SS
36		1	Gauge & Lever Assembly	42		1	Pivot Rod
37		1	Pivot & Bracket Assembly	43		1	Cross Brace, 11.25"
38		1	Spacer (pivot link)	44		1	Frame Brace
39		1	Wing Nut Assembly	45		1	1/4-20 x 2 Hex Cap Screw SS
40		1	Control Rod				
Accessories							
46*	WSC-030	1	Heavy-Duty Rain Cover	47*	PDK-030	1	3-Side Deflector Kit
SS = Stainless Steel							

* Accessory only.


TS-50 WALK-BEHIND BROADCAST SPREADER

OPTIONAL DEFLECTOR KIT COMPONENTS



TS-50 WALK-BEHIND BROADCAST SPREADER

DEFLECTOR KIT COMPONENTS



PDK-030* Deflector Kit							
Item	Part	Qty	Description	Item	Part	Qty	Description
1		1	Deflector Corner	8		1	Front Deflector Rod
2		1	Deflector Stop	9		1	Deflector Rod & Bracket Assy, Left
3		4	Deflector Cam	10		1	Deflector Rod & Bracket Assy, Right
4		2	Deflector Spacer	11		1	Deflector Assembly, Left
5		2	Side Deflector	12		1	Deflector Assembly, Right
6		1	Front Deflector	13		1	Deflector Assembly, Front
7		4	#10 x 5/8 Pan Head Phillips Head Screw				

* Accessory only.



TrynEx International
531 Ajax Drive
Madison Heights, MI 48071-2429
www.turfexproducts.com

 A DIVISION OF DOUGLAS DYNAMICS, LLC

Copyright © 2020 Douglas Dynamics, LLC. All rights reserved. This material may not be reproduced or copied, in whole or in part, in any printed, mechanical, electronic, film, or other distribution and storage media, without the written consent of TrynEx International, LLC. Authorization to photocopy items for internal or personal use by TrynEx International outlets or spreader owner is granted.

TrynEx International reserves the right under its product improvement policy to change construction or design details and furnish equipment when so altered without reference to illustrations or specifications used. TrynEx International may require or recommend optional equipment for spreaders. TrynEx International offers a limited warranty for all spreaders and accessories. See separately printed page for this important information. The following is a registered (®) trademark of Douglas Dynamics, LLC: TurfEx®.

Printed in U.S.A.